

Worldwide Consumable Parts Reference Guide

Updated: March 25, 2019
 Document Owner: WW Annuities Business Development
 Part Numbers and descriptions may be verified at the Lexmark Parts Store: https://shop.lexmark.com/wpo-catalog/US_en
 Information will be updated if content changes occur.
 This CPRG is only available in .pdf format for security/version-control purposes

COLOR SINGLE FUNCTION

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU	Yield Pages
BOLD: Currently in-Marketing	TYPE	PN	PNs Included	Description (Note 1)	(Note 2)	(Note 3)
C54x	5025			No MK announced for C540, C543 and C544, but C546 MK may be used on each. However, C540 does not use a duplex reference edge guide.		
C546	5025	40X2261	40X7564 40X7610 40X5803	C54x, X54x Fuser Maintenance kit, 100V Fuser assembly, 100V Transfer module assembly Duplex reference edge	FRU	60,000
		40X2254	40X7562 40X7610 40X5803	C54x, X54x Fuser Maintenance kit, 110-120V Fuser assembly, 110-120V Transfer module assembly Duplex reference edge	FRU	60,000
		40X2255	40X7563 40X7610 40X5803	C54x, X54x Fuser Maintenance kit, 220-240V Fuser assembly, 220-240V Transfer module assembly Duplex reference edge	FRU	60,000
		40X5168		Pick tires	CRU	
CS31x, CS41x, CS51x	5027	40X7617	40X7624 40X7610	CS/CX 310/410/510 Fuser+ITU Maintenance kit, 100V Fuser assembly, 100V Transfer module assembly	FRU	85,000
		40X7615	40X7622 40X7610	CS/CX 310/410/510 Fuser+ITU Maintenance kit, 110-120V Fuser assembly, 110-120V Transfer module assembly	FRU	85,000
		40X7616	40X7623 40X7610	CS/CX 310/410/510 Fuser+ITU Maintenance kit, 220-240V Fuser assembly, 220-240V Transfer module assembly	FRU	85,000
		40X5168		Pick tires	CRU	
CS42x, CS52x, CS62x C2325, C2425, C2535	5029	41X2095	41X1299 40X5168	CS/CX 42x, 52x, 62x Fuser Maintenance Kit, 100V CS/CX 42x, 52x, 62x Fuser, 100V Pick Tire	FRU	125,000
		41X2096	41X1041 40X5168	CS/CX 42x, 52x, 62x Fuser Maintenance Kit, 110V-120V CS/CX 42x, 52x, 62x Fuser, 110V-220V Pick Tire	FRU	125,000
		41X2097	41X1300 40X5168	CS/CX 42x, 52x, 62x Fuser Maintenance Kit, 220V-230V CS/CX 42x, 52x, 62x Fuser, 220V-230V Pick Tire	FRU	125,000
		41X1039		CS/CX 42x, 52x, 62x Image Transfer Unit (Note, this is not a consumable part; yield = life of printer; should not be considered in CPP and TCO calculations)	FRU	
CS72x	5028	41X0552	41X0251 41X0374 41X0956	CS72x CX72x Fuser Maintenance Kit, Type 02, 100V CS72x, CX72x Fuser, Type 02, 100V Separator Pad Pick Roller	CRU	150,000
		41X0554	41X0252 41X0374 41X0956	CS72x CX72x Fuser Maintenance Kit, Type 00, 110V-120V CS72x, CX72x Fuser, Type 00, 110V-120V Separator Pad Pick Roller	CRU	150,000
		41X0556	41X0253 41X0374 41X0956	CS72x CX72x Fuser Maintenance Kit, Type 01, 220V-240V CS72x, CX72x Fuser, Type 01, 220V-240V Separator Pad Pick Roller	CRU	150,000
		40X9929		Transfer Module	CRU	150,000
CS921, CS927	5059	41X1593	41X1459 41X1600 40X8970 40X9925	CS921, CS927, CX920, CX921, CX927 ITU Maintenance Kit CS/CX 92x Transfer Belt and Transfer Roller - (must be purchased together) Feed Separator Roller (2) and Pick Roller (1) Combo - qty 4 included in 41X1593 Feed Separator Roller (included in 41X1600) Pick Roller (included in 41X1600)	CRU	300,000
		41X1860		CS921, CS927, CX920, CX921, CX927 Fuser 120V	FRU	600,000
		41X1861		CS921, CS927, CX920, CX921, CX927 Fuser 230V	FRU	600,000
		41X2060		CS921, CS927, CX920, CX921, CX927 Fuser 100V (Japan only)	FRU	600,000
		41X2061		CS921, CS927, CX920, CX921, CX927 Fuser 110V (Taiwan only)	FRU	600,000
		41X1598		CS/CX 92x K Developer unit	FRU	600,000
		41X1594	41X1595 41X1596 41X1597	CS/CX 92x CMY Developer unit Maintenance Kit CS/CX 92x Developer C CS/CX 92x Developer M CS/CX 92x Developer Y	FRU	600,000
		41X1977		CS/CX 92x MPF Kit	FRU	200,000
		40X9995		MPF feed roller		
		40X9615		MPF separator roller		
CS923de	5059	41X2090	41X1459 41X1537 41X1600 40X8970 40X9925	CS923, CX922, CX923, CX924 ITU Maintenance Kit CS/CX 92x Transfer Belt and Transfer Roller - (must be purchased together) CS923, CX922, CX923, CX924 Toner Exhaust Filter Feed Separator Roller (2) and Pick Roller (1) Combo - qty 4 included in 41X2090 Feed Separator Roller (included in 41X1600) Pick Roller (included in 41X1600)	CRU	300,000
		41X1505		CS923, CX922, CX923, CX924 Universal Fuser Unit (100V, 110V, 120V, 230V)	FRU	720,000
		41X1598		CS/CX 92x K Developer unit	FRU	600,000
		41X1594	41X1595 41X1596 41X1597	CS/CX 92x CMY Developer unit Maintenance Kit CS/CX 92x Developer C CS/CX 92x Developer M CS/CX 92x Developer Y	FRU	600,000

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU	Yield
BOLD: Currently in-Marketing	TYPE	PN	PNs Included	Description (Note 1)	(Note 2)	(Note 3)
		41X1977		CS/CX 92x MPF Kit MPF feed roller MPF separator roller	FRU	200,000
C73x	5026	40X8112 40X8110 40X8111 40X6401 40X5152 40X5168	40X9995 40X9615	C73x, C74x, X73x, X74x Fuser Maintenance 100V C73x, C74x, X73x, X74x Fuser Maintenance 110-120V C73x, C74x, X73x, X74x Fuser Maintenance 220-240V Transfer module Maintenance Kit Pick arm roll Pick tires	CRU CRU CRU CRU CRU CRU	100,000 100,000 100,000 120,000
C74x	5026	40X8112 40X8110 40X8111 40X6401 40X5168 40X5152		C73x, C74x, X73x, X74x Fuser Maintenance 100V C73x, C74x, X73x, X74x Fuser Maintenance 110-120V C73x, C74x, X73x, X74x Fuser Maintenance 220-240V Transfer module Maintenance Kit Pick tires Pick arm roll	CRU CRU CRU CRU CRU CRU	100,000 100,000 100,000 120,000
C78x	5061	40X1833 40X1831 40X1832 40X0343 40X0070		C78x Fuser Maintenance Kit 100V C78x Fuser Maintenance Kit 110-120V C78x Fuser Maintenance Kit 220-240V C78x Image Transfer Unit Maintenance Kit Pick tire, pick roll assembly (2 per package)	FRU FRU FRU FRU FRU	120,000 120,000 120,000 120,000
C792	5062	40X7102 40X7100 40X7101 40X7103 40X6104 40X7178 40X6275		C792, X792 Fuser Maintenance Kit 100V C792, X792 Fuser Maintenance Kit 110-120V C792, X792 Fuser Maintenance Kit 220-240V C792, X792 Transfer module Maintenance Kit Pick tire roll MPF pick tire roll with wear strips C792, X792 High Capacity Feeder pick roll assembly	CRU CRU CRU CRU FRU FRU CRU	150,000 150,000 150,000 200,000
CS82x	5063	41X0927	41X0248 41X0245 41X0999	CS82x, CX82x, CX86x Combo Fuser & ITM Maintenance Kit, 100V CS82x, CX82x, CX86x Fuser, 100V Transfer Module Pick Roller and Separator Pad (3 with each Maintenance Kit)	CRU	300,000
		41X0928	41X0246 41X0245 41X0999	CS82x, CX82x, CX86x Combo Fuser & ITM Maintenance Kit, 110V-120V CS82x, CX82x, CX86x Fuser, 110V-120V Transfer Module Pick Roller and Separator Pad (3 with each Maintenance Kit)	CRU	300,000
		41X0929	41X0247 41X0245 41X0999	CS82x, CX82x, CX86x Combo Fuser & ITM Maintenance Kit, 220V-240V CS82x, CX82x, CX86x Fuser, 220V-240V Transfer Module Pick Roller and Separator Pad (3 with each Maintenance Kit)	CRU	300,000
C920	5056	40X1041 40X1077 40X1078 40X1079 40X1111		C920 Transfer Belt Maintenance Kit Pickup roller Paper feed roller Separator roller Feed roller (type 2, relay expansion)	FRU FRU FRU FRU FRU	120,000
C925	5041	40X6013 40X6093 40X6011 40X6372	40X6179 40X6180 40X6186 40X6580 40X6581 40X6579 40X6578 40X6457 40X6411	C925, X925 Fuser Maintenance Kit 110-120V C925, X925 Fuser Maintenance Kit 220-240V C925, X925 Transfer Belt and Roll (Maintenance) Paperfeed maintenance kit Feed roll Pick roll Separator roll MPF registration roller Standard registration roller Paper exit roller Multipurpose feeder roll Multipurpose feeder (MPF) Maintenance kit Multipurpose feeder (MPF) Maintenance kit Multipurpose feeder pad holder	CRU CRU CRU FRU	120,000 120,000 100,000 300,000
C935	5057	40X4032	40X3732 40X3746 40X3745 40X3744 40X3743 40X6788	C935, X940e, X945e Maintenance Kit, 600K Transfer belt unit assembly C developer carrier M developer carrier Y developer carrier K developer carrier Developer unit assembly	FRU	600,000
		40X7747	40X4153 40X3698 40X3733 40X0594	C935, X940e, X945e Maintenance Kit, 100K, 100V Fuser assembly 100 V 2nd transfer roll assembly Transfer belt cleaner assembly Feed/Pick/Separator Roll Kit	FRU	100,000
		40X4031	40X3747 40X3698 40X3733 40X0594	C935, X940e, X945e Maintenance Kit, 100K, 110-120V Fuser assembly 110 V 2nd transfer roll assembly Transfer belt cleaner assembly Feed/Pick/Separator Roll Kit	FRU	100,000
		40X4093	40X3748 40X3698 40X3733 40X0594	C935, X940e, X945e Maintenance Kit, 100K, 220-240V Fuser assembly 220 V 2nd transfer roll assembly Transfer belt cleaner assembly Feed/Pick/Separator Roll Kit	FRU	100,000
		40X0594 40X3711		Feed/Pick/Separator Roll Kit Multipurpose feeder pick roll kit		
C950	5058	40X7540	40X6623 40X6712 40X6599 40X6805	C950, X95x 160K Maintenance Kit Transfer belt cleaner 2nd Transfer roller Suction filter Feed roller kit	CRU	160,000
		40X7568	40X7532 40X6623 40X6712 40X6599 40X6805	C950, X95x Maintenance Kit, 320K, 100V Fuser assembly 100V Transfer belt cleaner 2nd Transfer roller Suction filter Feed roller kit	CRU	320,000 320,000 160,000
		40X7550	40X6629 40X6623 40X6712 40X6599 40X6805	C950, X95x Fuser Maintenance Kit, 320K, 110-120V Fuser assembly 110-120V Transfer belt cleaner 2nd Transfer roller Suction filter Feed roller kit	CRU	320,000 320,000 160,000
		40X7569		C950, X95x Fuser Maintenance Kit, 320K, 220-240V	CRU	320,000

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU	Yield
BOLD: Currently in-Marketing	TYPE	PN	PNs Included	Description (Note 1)	(Note 2)	(Note 3)
C950		40X7560	40X6630 40X6623 40X6712 40X6599 40X6805	Fuser assembly 220-240V Transfer belt cleaner 2nd Transfer roller Suction filter Feed roller kit		320,000 160,000
			40X6610 40X6611 40X6612 40X6609 40X6615 40X6615 40X6615 40X6615 40X6615 40X6624 40X6623 40X6712 40X6599 40X6805	C950, X95x 480K Maintenance Kit C Developer carrier M Developer carrier Y Developer carrier K Developer carrier Developer housing Developer housing Developer housing Developer housing Transfer belt assembly Transfer belt cleaner 2nd Transfer roller Suction filter Feed roller kit	FRU FRU FRU FRU FRU FRU FRU FRU FRU FRU CRU CRU CRU CRU	480,000 480,000 480,000 480,000 480,000 480,000 480,000 480,000 480,000 480,000 160,000 160,000 160,000 160,000
COLOR MULTIFUNCTION						
X54x	7525			No MK announced for X543 and X544, but X546 MK may be used on each.		
X546	7525	40X2261	40X7564 40X7610 40X5803	C54x, X54x Fuser Maintenance kit, 100V Fuser assembly, 100V Transfer module assembly Duplex reference edge	FRU	60,000
		40X2254	40X7562 40X7610 40X5803	C54x, X54x Fuser Maintenance kit, 110-120V Fuser assembly, 110-120V Transfer module assembly Duplex reference edge	FRU	60,000
		40X2255	40X7563 40X7610 40X5803	C54x, X54x Fuser Maintenance kit, 220-240V Fuser assembly, 220-240V Transfer module assembly Duplex reference edge	FRU	60,000
		40X5807	40X7545 40X8419	ADF maintenance kit ADF Separator roll Stress media separator pad	CRU	60,000
		40X5168		Pick tires	CRU	
X548	7525	40X2261	40X7564 40X7610 40X5803	C54x, X54x Fuser Maintenance kit, 100V Fuser assembly, 100V Transfer module assembly Duplex reference edge	FRU	60,000
		40X2254	40X7562 40X7610 40X5803	C54x, X54x Fuser Maintenance kit, 110-120V Fuser assembly, 110-120V Transfer module assembly Duplex reference edge	FRU	60,000
		40X2255	40X7563 40X7610 40X5803	C54x, X54x Fuser Maintenance kit, 220-240V Fuser assembly, 220-240V Transfer module assembly Duplex reference edge	FRU	60,000
		40X5807	40X7545 40X8419	ADF maintenance kit ADF Separator roll Stress media separator pad	CRU	60,000
		40X5168		Pick tires	CRU	
CX31x, CX41x, CX51x	7527	40X7617	40X7624 40X7610	CS/CX 310/410/510 Fuser+ITU Maintenance kit, 100V Fuser assembly, 100V Transfer module assembly	FRU	85,000
		40X7615	40X7622 40X7610	CS/CX 310/410/510 Fuser+ITU Maintenance kit, 110-120V Fuser assembly, 110-120V Transfer module assembly	FRU	85,000
		40X7616	40X7623 40X7610	CS/CX 310/410/510 Fuser+ITU Maintenance kit, 220-240V Fuser assembly, 220-240V Transfer module assembly	FRU	85,000
		40X9110 40X6247 41X0917 40X5168		ADF Pick Roll pad CX310 ADF Separator Pad ADF Separator Roller Pick tires	CRU CRU CRU CRU	
CX42x, CX52x MC2325, MC2425, MC2535	7529	41X2095	41X1299 40X5168	CS/CX 42x, 52x, 62x Fuser Maintenance Kit, 100V CS/CX 42x, 52x, 62x Fuser, 100V Pick Tire	FRU	125,000
		41X2096	41X1041 40X5168	CS/CX 42x, 52x, 62x Fuser Maintenance Kit, 110V-120V CS/CX 42x, 52x, 62x Fuser, 110V-220V Pick Tire	FRU	125,000
		41X2097	41X1300 40X5168	CS/CX 42x, 52x, 62x Fuser Maintenance Kit, 220V-230V CS/CX 42x, 52x, 62x Fuser, 220V-230V Pick Tire	FRU	125,000
		41X1039 41X0917 40X8736		CS/CX 42x, 52x, 62x Image Transfer Unit (Note, this is not a consumable part; yield = life of printer; should not be considered in CPP and TCO calculations) CX42x, CX52x ADF Separator Roll CX42x, CX52x, CX72x ADF Pick Roll	FRU CRU FRU	
CX62x MC2640	7529	41X2095	41X1299 40X5168	CS/CX 42x, 52x, 62x Fuser Maintenance Kit, 100V CS/CX 42x, 52x, 62x Fuser, 100V Pick Tire	FRU	125,000
		41X2096	41X1041 40X5168	CS/CX 42x, 52x, 62x Fuser Maintenance Kit, 110V-120V CS/CX 42x, 52x, 62x Fuser, 110V-220V Pick Tire	FRU	125,000
		41X2097	41X1300 40X5168	CS/CX 42x, 52x, 62x Fuser Maintenance Kit, 220V-230V CS/CX 42x, 52x, 62x Fuser, 220V-230V Pick Tire	FRU	125,000
		41X1039 41X1325 41X1326		CS/CX 42x, 52x, 62x Image Transfer Unit (Note, this is not a consumable part; yield = life of printer; should not be considered in CPP and TCO calculations) CX62x DADF Separator Roll CX62x ADF Pick Roll	FRU CRU FRU	
CX72x	7528	41X0552	41X0251 41X0374 41X0956	CS72x CX72x Fuser Maintenance Kit, Type 02, 100V CS72x, CX72x Fuser, Type 02, 100V Separator Pad Pick Roller	CRU	150,000
		41X0554	41X0252 41X0374	CS72x CX72x Fuser Maintenance Kit, Type 00, 110V-120V CS72x, CX72x Fuser, Type 00, 110V-120V Separator Pad	CRU	150,000

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU	Yield Pages
BOLD: Currently in-Marketing	TYPE	PN	PNs Included	Description (Note 1)	(Note 2)	(Note 3)
		41X0556	41X0956	Pick Roller	CRU	150,000
			41X0253	CS72x CX72x Fuser Maintenance Kit, Type 01, 220V-240V		
			41X0374	CS72x, CX72x Fuser, Type 01, 220V-240V		
			41X0956	Separator Pad		
		40X9929		Pick Roller		
		40X8736		Transfer Module	CRU	150,000
		41X0917		ADF Pick Roller		220,000
				ADF Separator Roller		220,000
CX920, CX921, CX927	7559	41X1593	41X1459	CS921, CS927, CX920, CX921, CX927 ITU Maintenance Kit	CRU	300,000
			41X1600	CS/CX 92x Transfer Belt and Transfer Roller - (must be purchased together)		
			40X8970	Feed Separator Roller (2) and Pick Roller (1) Combo - qty 4 included in 41X1593		
			40X9925	Feed Separator Roller (included in 41X1600)		
				Pick Roller (included in 41X1600)		
		41X1860		CS921, CS927, CX920, CX921, CX927 Fuser 120V	FRU	600,000
		41X1861		CS921, CS927, CX920, CX921, CX927 Fuser 230V		
		41X2060		CS921, CS927, CX920, CX921, CX927 Fuser 100V (Japan only)		
		41X2061		CS921, CS927, CX920, CX921, CX927 Fuser 110V (Taiwan only)		
		41X1598		CS/CX 92x K Developer unit	FRU	600,000
		41X1594		CS/CX 92x CMY Developer unit Maintenance Kit	FRU	600,000
			41X1595	CS/CX 92x Developer C		
			41X1596	CS/CX 92x Developer M		
			41X1597	CS/CX 92x Developer Y		
		41X1977		CS/CX 92x MPF Kit	FRU	200,000
			40X9995	MPF feed roller		
			40X9615	MPF separator roller		
		41X1592		CX 92x ADF Kit (200K)	CRU	200,000
			41X1404	ADF Feed & Pick Roller Assembly		
			40X9682	ADF Separation roller		
			41X1601	ADF Separator roller spring		
CX922, CX923, CX924	7559	41X2090	41X1459	CS923, CX922, CX923, CX924 ITU Maintenance Kit	CRU	300,000
			41X1537	CS/CX 92x Transfer Belt and Transfer Roller - (must be purchased together)		
			41X1600	CS923, CX922, CX923, CX924 Toner Exhaust Filter		
			40X8970	Feed Separator Roller (2) and Pick Roller (1) Combo - qty 4 included in 41X2090		
			40X9925	Feed Separator Roller (included in 41X1600)		
				Pick Roller (included in 41X1600)		
		41X1505		CS923, CX922, CX923, CX924 Universal Fuser Unit (100V, 110V, 120V, 230V)	FRU	720,000
		41X1598		CS/CX 92x K Developer unit	FRU	600,000
		41X1594		CS/CX 92x CMY Developer unit Maintenance Kit	FRU	600,000
			41X1595	CS/CX 92x Developer C		
			41X1596	CS/CX 92x Developer M		
			41X1597	CS/CX 92x Developer Y		
		41X1977		CS/CX 92x MPF Kit	FRU	200,000
			40X9995	MPF feed roller		
			40X9615	MPF separator roller		
		41X1592		CX 92x ADF Kit (200K)	CRU	200,000
			41X1404	ADF Feed & Pick Roller Assembly		
			40X9682	ADF Separation roller		
			41X1601	ADF Separator roller spring		
X73x	7526	40X8112		C73x, C74x, X73x, X74x Fuser Maintenance 100V	CRU	100,000
		40X8110		C73x, C74x, X73x, X74x Fuser Maintenance 110-120V	CRU	100,000
		40X8111		C73x, C74x, X73x, X74x Fuser Maintenance 220-240V	CRU	100,000
		40X6401		Transfer module Maintenance Kit	CRU	120,000
		40X5152		Pick arm roll	CRU	
		40X5168		Pick tires	CRU	
		40X5187		ADF separator pad	CRU	30,000
		40X5188		ADF pick roll assembly	CRU	120,000
		40X5189		ADF pick pad	CRU	200,000
X74x	7526	40X8112		C73x, C74x, X73x, X74x Fuser Maintenance 100V	CRU	100,000
		40X8110		C73x, C74x, X73x, X74x Fuser Maintenance 110-120V	CRU	100,000
		40X8111		C73x, C74x, X73x, X74x Fuser Maintenance 220-240V	CRU	100,000
		40X6401		Transfer module Maintenance Kit	CRU	120,000
		40X5168		Pick tires	CRU	
		40X5152		Pick arm roll	CRU	
		40X5187		ADF separator pad	CRU	30,000
		40X5188		ADF pick roll assembly	CRU	120,000
		40X5189		ADF pick pad	CRU	200,000
X782	4036	40X1833		C78x Fuser Maintenance Kit 100V	FRU	120,000
		40X1831		C78x Fuser Maintenance Kit 110-120V	FRU	120,000
		40X1832		C78x Fuser Maintenance Kit 220-240V	FRU	120,000
		40X0343		C78x Image Transfer Unit Maintenance Kit	FRU	120,000
		40X0070		Pick tire, pick roll assembly (2 per package)	FRU	
X792	7542	40X7102		C792, X792 Fuser Maintenance Kit 100V	CRU	150,000
		40X7100		C792, X792 Fuser Maintenance Kit 110-120V	CRU	150,000
		40X7101		C792, X792 Fuser Maintenance Kit 220-240V	CRU	150,000
		40X7103		C792, X792 Transfer module Maintenance Kit	CRU	200,000
		40X7220		X792, XS796 ADF Maintenance Kit	CRU	120,000
		40X6104		Pick tire roll	FRU	
		40X7178		MPF pick tire roll with wear strips	FRU	
		40X6275		C792, X792 High Capacity Feeder pick roll assembly	FRU	
CX82x	7563	41X0927		CS82x, CX82x, CX86x Combo Fuser & ITM Maintenance Kit, 100V	CRU	300,000
			41X0248	CS82x, CX82x, CX86x Fuser, 100V		
			41X0245	Transfer Module		
			41X0999	Pick Roller and Separator Pad (3 with each Maintenance Kit)		
		41X0928		CS82x, CX82x, CX86x Combo Fuser & ITM Maintenance Kit, 110V-120V	CRU	300,000
			41X0246	CS82x, CX82x, CX86x Fuser, 110V-120V		
			41X0245	Transfer Module		
			41X0999	Pick Roller and Separator Pad (3 with each Maintenance Kit)		
		41X0929		CS82x, CX82x, CX86x Combo Fuser & ITM Maintenance Kit, 220V-240V	CRU	300,000
			41X0247	CS82x, CX82x, CX86x Fuser, 220V-240V		
			41X0245	Transfer Module		
			41X0999	Pick Roller and Separator Pad (3 with each Maintenance Kit)		
		41X0931		ADF Maintenance Kit	CRU	200,000
			41X0359	ADF Feed Belt		

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU	Yield Pages	
BOLD: Currently in-Marketing	TYPE	PN	PNS Included	Description (Note 1)	(Note 2)	(Note 3)	
CX86x	7563	41X0927	41X0248 41X0245 41X0999	CS82x, CX82x, CX86x Combo Fuser & ITM Maintenance Kit, 100V CS82x, CX82x, CX86x Fuser, 100V Transfer Module Pick Roller and Separator Pad (3 with each Maintenance Kit)	CRU	300,000	
		41X0928	41X0246 41X0245 41X0999	CS82x, CX82x, CX86x Combo Fuser & ITM Maintenance Kit, 110V-120V CS82x, CX82x, CX86x Fuser, 110V-120V Transfer Module Pick Roller and Separator Pad (3 with each Maintenance Kit)	CRU	300,000	
		41X0929	41X0247 41X0245 41X0999	CS82x, CX82x, CX86x Combo Fuser & ITM Maintenance Kit, 220V-240V CS82x, CX82x, CX86x Fuser, 220V-240V Transfer Module Pick Roller and Separator Pad (3 with each Maintenance Kit)	CRU	300,000	
		41X0931	41X0359	ADF Maintenance Kit ADF Feed Belt	CRU	200,000	
		X925	7541	40X6013 40X6093 40X6011 40X6372	C925, X925 Fuser Maintenance Kit 110-120V C925, X925 Fuser Maintenance Kit 220-240V C925, X925 Transfer Belt and Roll (Maintenance) Paperfeed maintenance kit Feed roll Pick roll Separator roll MPF registration roller Standard registration roller Paper exit roller Multipurpose feeder roll Multipurpose feeder (MPF) Maintenance kit	CRU CRU CRU FRU	120,000 120,000 100,000 300,000
		40X6457	40X6411 XXXXXX	Multipurpose feeder (MPF) Maintenance kit Multipurpose feeder pad holder Multipurpose pad	FRU	100,000	
		40X6327 40X6328		ADF pick roll assembly ADF separator roll	CRU CRU	200,000 100,000	
X94x	7510	40X4032	40X3732 40X3746 40X3745 40X3744 40X3743 40X6788	C935, X940e, X945e Maintenance Kit, 600K Transfer belt unit assembly C developer carrier M developer carrier Y developer carrier K developer carrier Developer unit assembly	FRU	600,000	
		40X7747	40X4153 40X3698 40X3733 40X0594	C935, X940e, X945e Maintenance Kit, 100K, 100V Fuser assembly 100 V 2nd transfer roll assembly Transfer belt cleaner assembly Feed/Pick/Separator Roll Kit	FRU	100,000	
		40X4031	40X3747 40X3698 40X3733 40X0594	C935, X940e, X945e Maintenance Kit, 100K, 110-120V Fuser assembly 110 V 2nd transfer roll assembly Transfer belt cleaner assembly Feed/Pick/Separator Roll Kit	FRU	100,000	
		40X4093	40X3748 40X3698 40X3733 40X0594	C935, X940e, X945e Maintenance Kit, 100K, 220-240V Fuser assembly 220 V 2nd transfer roll assembly Transfer belt cleaner assembly Feed/Pick/Separator Roll Kit	FRU	100,000	
		40X4033	40X2273 40X3887	X940e, X945e ADF Maintenance Kit Separation roll guide assembly (assembled) ADF feed/pick roll assembly (assembled)	FRU	150,000	
		40X0594 40X3711		Feed/Pick/Separator Roll Kit Multipurpose feeder pick roll kit			
		X95x	7558	40X7540	C950, X95x 160K Maintenance Kit Transfer belt cleaner 2nd Transfer roller Suction filter Feed roller kit	CRU	160,000
		40X7568	40X7532 40X6623 40X6712 40X6599 40X6805	C950, X95x Maintenance Kit, 320K, 100V Fuser assembly 100V Transfer belt cleaner 2nd Transfer roller Suction filter Feed roller kit	CRU	320,000 320,000 160,000	
		40X7550	40X6629 40X6623 40X6712 40X6599 40X6805	C950, X95x Fuser Maintenance Kit, 320K, 110-120V Fuser assembly 110-120V Transfer belt cleaner 2nd Transfer roller Suction filter Feed roller kit	CRU	320,000 320,000 160,000	
		40X7569	40X6630 40X6623 40X6712 40X6599 40X6805	C950, X95x Fuser Maintenance Kit, 320K, 220-240V Fuser assembly 220-240V Transfer belt cleaner 2nd Transfer roller Suction filter Feed roller kit	CRU	320,000 320,000 160,000	
40X7560	40X6610 40X6611 40X6612 40X6609 40X6615 40X6615 40X6615 40X6615 40X6615 40X6624 40X6623 40X6712 40X6599 40X6805	C950, X95x 480K Maintenance Kit C Developer carrier M Developer carrier Y Developer carrier K Developer carrier Developer housing Developer housing Developer housing Developer housing Developer housing Transfer belt assembly Transfer belt cleaner 2nd Transfer roller Suction filter Feed roller kit	FRU FRU FRU FRU FRU FRU FRU FRU FRU FRU FRU FRU CRU CRU CRU CRU CRU	480,000 480,000 480,000 480,000 480,000 480,000 480,000 480,000 480,000 480,000 480,000 480,000 160,000 160,000 160,000 200,000			
40X7530	40X6824 40X6821	X95x ADF Maintenance Kit ADF feed /pick roller assembly ADF separation roller guide	CRU	200,000			

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU	Yield
BOLD: Currently in-Marketing	TYPE	PN	PNs Included	Description (Note 1)	(Note 2)	(Note 3)
MONO SINGLE FUNCTION						
E26x, E36x	4513			(No Maintenance Kit announced, but E46x Maintenance Kit may be used.)		
MS31x, MS41x	4514	40X8343 40X8023 40X8024 40X8298 41X0918 40X8393 40X8443 40X8295		No Maintenance Kit (MK) announced and no Schedule 80 warning will appear on MS31x or MS41x. However, the MS51x MK may be used and the published yield remains at 150,000 pages. 100V Fuser 110V Fuser 220V Fuser Redrive roller assembly Pick Tire Transfer Roll Pick roll assembly for optional trays MPF Pick Roller and Separator Pad	FRU FRU FRU FRU CRU FRU FRU FRU	150,000 150,000 150,000 200,000 150,000 200,000 200,000 50,000
MS32x, MS42x B23x, B24x	4600	41X1180 41X1178 41X1179 40X8393 41X0918 41X1197 41X1239 41X1212		No Maintenance Kit (MK) announced and no Schedule 80 warning will appear on MS32x or MS42x. However, the MS52x MK may be used and the published yield remains at 200,000 pages. Fuser, 100V Fuser, 110V Fuser, 220V Transfer Roll Pick Tire MPF Pick Roller and Separator Pad Pick Roll Separator Roll Assembly	FRU FRU FRU FRU CRU FRU FRU FRU	150,000 150,000 150,000 200,000 200,000 50,000 200,000 200,000
B2236	1400	41X2463 41X2464 41X2455 41X2457		No Maintenance Kit (MK) announced / no Schedule 80 warning will appear on B2236, MB2236 models. The yield of the consumable parts below are equivalent to the printer life, and therefore should not be considered in any TCO or CPP calculations. Fuser, 110V Fuser, 220V Pick Roller Transfer Roller	FRU FRU FRU FRU	
E460, E462	4513	40X5402	40X5346 40X5451 40X5364 40X5400 40X5344 40X5451 40X5364 40X5401 40X5345 40X5451 40X5364	E46x, X46x Fuser Maintenance Kit 100V Fuser assembly, 100V Paper feed, ACM tires Transfer roll, bearings, gear, spring (CBM) E46x, X46x Fuser Maintenance Kit 110-120V Fuser assembly, 110-120V Paper feed, ACM tires Transfer roll, bearings, gear, spring (CBM) E46x, X46x Fuser Maintenance Kit 220-240V Fuser assembly, 220-240V Paper feed, ACM tires Transfer roll, bearings, gear, spring (CBM)	FRU FRU FRU	120,000 120,000 120,000
MS51x	4514	40X8439 40X8281 40X8282 40X8443	40X8343 40X8298 41X0918 41X0958 40X8393 40X8444 40X8295 40X8023 40X8298 41X0918 41X0958 40X8393 40X8444 40X8295 40X8024 40X8298 41X0918 41X0958 40X8393 40X8444 40X8295 40X8443	MS510 Fuser Maintenance Kit, 100V Fuser, 100V Redrive assembly Pick Tire Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad MS510 Fuser Maintenance Kit, 110-120V Fuser, 110-120V Redrive assembly Pick Tire Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad MS510 Fuser Maintenance Kit, 220-240V Fuser, 220-240V Redrive assembly Pick Tire Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad Pick roll assembly for optional trays	FRU FRU FRU CRU	200,000 200,000 200,000 200,000
MS52x B25x	4600	41X1230 41X1228 41X1229 41X1239 41X1212	41X1180 41X1197 41X0918 40X8393 41X1178 41X1197 41X0918 40X8393 41X1179 41X1197 41X0918 40X8393	MS521 Fuser Maintenance Kit, 100V Fuser, 100V MPF Pick Roller and Separator Pad Pick Tire Transfer Roll MS521 Fuser Maintenance Kit, 110V Fuser, 110V MPF Pick Roller and Separator Pad Pick Tire Transfer Roll MS521 Fuser Maintenance Kit, 220V Fuser, 220V MPF Pick Roller and Separator Pad Pick Tire Transfer Roll Pick Roll Separator Roll Assembly	FRU FRU FRU CRU FRU	200,000 200,000 200,000 200,000 200,000
MS610dn/dtn	4514	40X8440 40X8433	40X8343 40X8437 41X0958 40X8393 40X8444 40X8295 40X8023 40X8437 41X0958 40X8393 40X8444 40X8295	MS610dn/dtn Fuser Maintenance Kit, 100V Fuser, 100V Redrive assembly, MS610dn/dtn Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad MS610dn/dtn Fuser Maintenance Kit, 110-120V Fuser, 110-120V Redrive assembly, MS610dn/dtn Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad	FRU FRU	200,000 200,000

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU (Note 2)	Yield Pages (Note 3)
BOLD: Currently in-Marketing	TYPE	PN	PNs Included	Description (Note 1)		
MS610dn/dtn		40X8435	40X8024 40X8437 41X0958 40X8393 40X8444 40X8295	MS610dn/dtn Fuser Maintenance Kit, 220-240V Fuser, 220-240V Redrive assembly, MS610dn/dtn Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad	FRU	200,000
		40X8443		Pick roll assembly for optional trays	CRU	
MS610de/dte		40X8441	40X8343 40X8438 41X0958 40X8393 40X8444 40X8295	MS610de/dte Fuser Maintenance Kit, 100V Fuser, 100V Redrive assembly, MS610de/dte Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad	FRU	200,000
		40X8434	40X8023 40X8438 41X0958 40X8393 40X8444 40X8295	MS610de/dte Fuser Maintenance Kit, 110-120V Fuser, 110-120V Redrive assembly, MS610de/dte Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad	FRU	200,000
		40X8436	40X8024 40X8438 41X0958 40X8393 40X8444 40X8295	MS610de/dte Fuser Maintenance Kit, 220-240V Fuser, 220-240V Redrive assembly, MS610de/dte Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad	FRU	200,000
		40X8443		Pick roll assembly for optional trays	CRU	
MS62x B26x	4600	41X1227	41X1180 41X1197 41X1198 41X1212 40X8393	MS621, MS622 Fuser Maintenance Kit, 100V Fuser, 100V MPF Pick Roller and Separator Pad Pick Tire Separator Roll Assembly Transfer Roll	FRU	200,000
		41X1225	41X1178 41X1197 41X1198 41X1212 40X8393	MS621, MS622 Fuser Maintenance Kit, 110V Fuser, 110V MPF Pick Roller and Separator Pad Pick Tire Separator Roll Assembly Transfer Roll	FRU	200,000
		41X1226	41X1179 41X1197 41X1198 41X1212 40X8393	MS621, MS622 Fuser Maintenance Kit, 200V Fuser, 200V MPF Pick Roller and Separator Pad Pick Tire Separator Roll Assembly Transfer Roll	FRU	200,000
		41X1239		Pick Roll	CRU	200,000
T61x	4069		40X4308 99A1017 40X4308	Pick roll assembly (2 per package) Opra M410, M412 Charge Roll Kit Pick roll assembly (2 per package)		
T614, T616	4069		99A1017 40X4308 99A1017 40X4308	Opra M410, M412 Charge Roll Kit Pick roll assembly (2 per package) Opra M410, M412 Charge Roll Kit Pick roll assembly (2 per package)		
T620	4069		99A1017 40X4308 99A1017 40X4308	Opra M410, M412 Charge Roll Kit Pick roll assembly (2 per package) Opra M410, M412 Charge Roll Kit Pick roll assembly (2 per package)		
T622	4069		99A1017 40X4308 99A1017 40X4308	Opra M410, M412 Charge Roll Kit Pick roll assembly (2 per package) Opra M410, M412 Charge Roll Kit Pick roll assembly (2 per package)		
T630, T632	4069	56P1409	56P2542 99A0179 99A1017 40X4308 56P2544 99A0179 99A1017 40X4308	T630, T632 Fuser Maintenance Kit 110-120V Fuser assembly w/115V lamp, 000/010/200/210 Transfer roll assembly Opra M410, M412 Charge Roll Kit Pick roll assembly (2 per package) Fuser assembly w/220V lamp, 000/010/200/210 Transfer roll assembly Opra M410, M412 Charge Roll Kit Pick roll assembly (2 per package)	FRU	300,000
T634	4060		99A0179 99A1017 40X4308 56P2546 99A0179 99A1017 40X4308	Transfer roll assembly Opra M410, M412 Charge Roll Kit Pick roll assembly (2 per package) Fuser assembly w/220V lamp, 400/410 Transfer roll assembly Opra M410, M412 Charge Roll Kit Pick roll assembly (2 per package)		
T64x	7002	40X0100	40X0127 40X0130 40X4308	Dual Charge roll assembly Transfer roll assembly Pick roll assembly (2 per package)	FRU	300,000
		40X0101	40X2592 40X0127 40X0130 40X4308	T64x, X642e, X644e, X646e Fuser Maintenance Kit 110-120V Fuser assembly w/115 V lamp Dual Charge roll assembly Transfer roll assembly Pick roll assembly (2 per package)	FRU	300,000
		40X0076	40X2590 40X0127 40X0130 40X4308	T64x, X642e, X644e, X646e Fuser Maintenance Kit 220-240V Fuser assembly w/220 V lamp Dual Charge roll assembly Transfer roll assembly Pick roll assembly (2 per package)	FRU	300,000
		40X4723		Pick roll assembly	CRU	
T65x	4062	40X4723	40X1870 40X0127 40X1886 40X4308	T65x, X65xe Fuser Maintenance Kit 100V Fuser assembly 100V, type 1 Dual Charge roll assembly Transfer roll assembly with tool Pick roll assembly (2 per package)	CRU	300,000

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU (Note 2)	Yield Pages (Note 3)				
BOLD: Currently in-Marketing	TYPE	PN	PNs Included	Description (Note 1)						
T65x		40X4766	40X5853 40X0127 40X1886 40X4308	Maintenance Kit 100V (Type 2) Fuser assembly 100V, type 2 Dual Charge roll assembly Transfer roll assembly with tool Pick roll assembly (2 per package)	CRU	150,000				
		40X4724	40X4418 40X0127 40X1886 40X4308	T65x, X65xe Fuser Maintenance Kit 110-120V Fuser assembly 110-120V, type 1 Dual Charge roll assembly Transfer roll assembly with tool Pick roll assembly (2 per package)	CRU	300,000				
		40X4767	40X5854 40X0127 40X1886 40X4308	Maintenance Kit 110-127V Type 2 Fuser assembly 110-120V, type 2 Dual Charge roll assembly Transfer roll assembly with tool Pick roll assembly (2 per package)	CRU	150,000				
		40X4765	40X1871 40X0127 40X1886 40X4308	T65x, X65xe Fuser Maintenance Kit 220-240V Fuser assembly 220-240V, type 1 Dual Charge roll assembly Transfer roll assembly with tool Pick roll assembly (2 per package)	CRU	300,000				
		40X4768	40X5855 40X0127 40X1886 40X4308	Maintenance Kit 220-240V Type 2 Fuser assembly 220-240V, type 2 Dual Charge roll assembly Transfer roll assembly with tool Pick roll assembly (2 per package)	CRU	150,000				
		MS71x	4063	40X7706	40X7593 40X7582 40X7713	MS81x, MX71x, MX81x Roller Maintenance Kit Pick roller assembly Transfer roller Separator roller assembly	CRU	300,000		
40X8530	40X8503 40X7593 40X7582 40X7713			MS71x Return Program Fuser Maintenance kit, 110-120V, Type 11 MS71x Return Program Fuser, 110-120V, Type 11 Pick roller assembly Transfer roller Separator roller assembly	CRU	200,000				
40X8531	40X8504 40X7593 40X7582 40X7713			MS71x Return Program Fuser Maintenance kit, 220-240V, Type 13 MS71x Return Program Fuser, 220-240V, Type 13 Pick roller assembly Transfer roller Separator roller assembly	CRU	200,000				
40X8532	40X8505 40X7593 40X7582 40X7713			MS71x Return Program Fuser Maintenance kit, 100V, Type 15 MS71x Return Program Fuser, 100V, Type 15 Pick roller assembly Transfer roller Separator roller assembly	CRU	200,000				
40X8533	40X8506 40X7593 40X7582 40X7713			MS71x Fuser Maintenance kit, 110-120V, Type 17 MS71x Fuser, 110-120V, Type 17 Pick roller assembly Transfer roller Separator roller assembly	CRU	200,000				
40X8534	40X8507 40X7593 40X7582 40X7713			MS71x Fuser Maintenance kit, 220-240V, Type 19 MS71x Fuser, 220-240V, Type 19 Pick roller assembly Transfer roller Separator roller assembly	CRU	200,000				
40X8535	40X8508 40X7593 40X7582 40X7713			MS71x Fuser Maintenance kit, 100V, Type 21 MS71x Fuser, 100V, Type 21 Pick roller assembly Transfer roller Separator roller assembly	CRU	200,000				
MS725	4064			41X2352	41X1076 41X1108 41X1119	MS72x, MX72x, MS82x, MX82x Roller Maintenance Kit Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	450,000		
				41X2242	41X2147 41X1076 41X1108 41X1119	MS725, MX725 Return Program Fuser Maintenance Kit, 115V, Type 11 MS725, MX725 Return Program Fuser, 115V, Type 11 Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000		
				41X2243	41X2148 41X1076 41X1108 41X1119	MS725, MX725 Return Program Fuser Maintenance Kit, 220V, Type 13 MS725, MX725 Retrn Program Fuser, 220V, Type 13 Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000		
				41X2244	41X2149 41X1076 41X1108 41X1119	MS725, MX725 Fuser Maintenance Kit, 115V, Type 17 MS725, MX725 Fuser, 115V, Type 17 Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000		
				41X2245	41X2150 41X1076 41X1108 41X1119	MS725, MX725 Fuser Maintenance Kit, 220V, Type 19 MS725, MX725 Fuser, 220V, Type 19 Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000		
				MS81x	4063	40X7706	40X7593 40X7582 40X7713	MS81x, MX71x, MX81x Roller Maintenance Kit Pick roller assembly Transfer roller Separator roller assembly	CRU	300,000
						40X8420	40X7743 40X7593 40X7582 40X7713	MS81x, MX71x, MX81x Return Program Fuser Maintenance kit, 110-120V, Type 00, Ltr MS81x, MX71x, MX81x Return Program Fuser, 110-120V, Type 00, Ltr Pick roller assembly Transfer roller Separator roller assembly	CRU	200,000
		40X8421	40X7744 40X7593 40X7582 40X7713			MS81x, MX71x, MX81x Return Program Fuser Maintenance kit, 220-240V, Type 01, A4 MS81x, MX71x, MX81x Return Program Fuser, 220-240V, Type 01, A4 Pick roller assembly Transfer roller Separator roller assembly	CRU	200,000		
40X8422	40X7745 40X7593 40X7582	MS81x, MX71x, MX81x Return Program Fuser Maintenance kit, 100V, Type 02, A4 MS81x, MX71x, MX81x Return Program Fuser, 100V, Type 02, A4 Pick roller assembly Transfer roller	CRU			200,000				

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU	Yield Pages	
BOLD: Currently in-Marketing	TYPE	PN	PNs Included	Description (Note 1)	(Note 2)	(Note 3)	
MS81x		40X8423	40X7713	Separator roller assembly MS81x, MX71x, MX81x Return Program Fuser Maintenance kit, 110-120V, Type 03, A4	CRU	200,000	
			40X7581	MS81x, MX71x, MX81x Return Program Fuser, 110-120V, Type 03, A4			
			40X7593	Pick roller assembly			
			40X7582	Transfer roller			
			40X7713	Separator roller assembly			
		40X8424	40X7734	MS81x, MX71x, MX81x Return Program Fuser Maintenance kit, 220-240V, Type 04, Ltr	CRU	200,000	
			40X7593	MS81x, MX71x, MX81x Return Program Fuser, 220-240V, Type 04, Ltr			
			40X7582	Pick roller assembly			
			40X7713	Transfer roller			
			40X8425	40X8016	MS81x, MX71x, MX81x Fuser Maintenance kit, 110-120V, Type 05, Ltr	CRU	200,000
			40X7593	MS81x, MX71x, MX81x Fuser, 110-120V, Type 05, Ltr			
			40X7582	Pick roller assembly			
			40X7713	Transfer roller			
40X8426	40X8017	MS81x, MX71x, MX81x Fuser Maintenance kit, 220-240V, Type 06, A4	CRU	200,000			
	40X7593	MS81x, MX71x, MX81x Fuser, 220-240V, Type 06, A4					
	40X7582	Pick roller assembly					
	40X7713	Transfer roller					
40X8427	40X8018	MS81x, MX71x, MX81x Fuser Maintenance kit, 100V, Type 07, A4	CRU	200,000			
	40X7593	MS81x, MX71x, MX81x Fuser, 100V, Type 07, A4					
	40X7582	Pick roller assembly					
	40X7713	Transfer roller					
40X8428	40X8019	MS81x, MX71x, MX81x Fuser Maintenance kit, 110-120V, Type 08, A4	CRU	200,000			
	40X7593	MS81x, MX71x, MX81x Fuser, 110-120V, Type 08, A4					
	40X7582	Pick roller assembly					
	40X7713	Transfer roller					
40X8429	40X8020	MS81x, MX71x, MX81x Fuser Maintenance kit, 220-240V, Type 09, Ltr	CRU	200,000			
	40X7593	MS81x, MX71x, MX81x Fuser, 220-240V, Type 09, Ltr					
	40X7582	Pick roller assembly					
	40X7713	Transfer roller					
	40X7600	Separator roller assembly					
MS82x, B2865	4064	41X2352		Multipurpose feeder pick roller	FRU		
				MS72x, MX72x, MS82x, MX82x Roller Maintenance Kit	CRU	450,000	
			41X1076	Transfer Roll			
			41X1108	Pick Roll (Qtyt 3)			
			41X1119	Separator Pad (Qty 3)			
		41X2233	41X1115	MS82x, MX721, MX722, MX82x Return Program Fuser Maintenance Kit, 115V, Type 00, Letter	CRU	225,000	
			41X1076	MS82x, MX721, MX722, MX82x Return Program Fuser, 115V, Type 00, Letter			
			41X1108	Transfer Roll			
			41X1119	Pick Roll (Qtyt 3)			
			41X1119	Separator Pad (Qty 3)			
		41X2234	41X1116	MS82x, MX721, MX722, MX82x Return Program Fuser Maintenance Kit, Type 01, 230V, A4	CRU	225,000	
			41X1076	MS82x, MX721, MX722, MX82x Return Program Fuser, 230V, Type 01, A4			
			41X1108	Transfer Roll			
			41X1119	Pick Roll (Qtyt 3)			
			41X1119	Separator Pad (Qty 3)			
		41X2235	41X1117	MS82x, MX721, MX722, MX82x Return Program Fuser Maintenance Kit, 100V, Type 02, A4	CRU	225,000	
			41X1076	MS82x, MX721, MX722, MX82x Return Program Fuser, 100V, Type 02, A4			
			41X1108	Transfer Roll			
			41X1119	Pick Roll (Qtyt 3)			
			41X1119	Separator Pad (Qty 3)			
		41X2236	41X2141	MS82x, MX721, MX722, MX82x Return Program Fuser Maintenance Kit, 115V, Type 03, A4	CRU	225,000	
			41X1076	MS82x, MX721, MX722, MX82x Return Program Fuser, 115V, Type 03, A4			
			41X1108	Transfer Roll			
			41X1119	Pick Roll (Qtyt 3)			
			41X1119	Separator Pad (Qty 3)			
		41X2237	41X2142	MS82x, MX721, MX722, MX82x Return Program Fuser Maintenance Kit, 230V, Type 04, Letter	CRU	225,000	
			41X1076	MS82x, MX721, MX722, MX82x Return Program, Fuser, 230V, Type 04, Letter			
			41X1108	Transfer Roll			
			41X1119	Pick Roll (Qtyt 3)			
			41X1119	Separator Pad (Qty 3)			
		41X2238	41X2143	MS82x, MX721, MX722, MX82x Fuser Maintenance Kit, 115V, Type 05, Letter	CRU	225,000	
			41X1076	MS82x, MX721, MX722, MX82x Fuser, 115V, Type 05, Letter			
	41X1108	Transfer Roll					
	41X1119	Pick Roll (Qtyt 3)					
	41X1119	Separator Pad (Qty 3)					
41X2239	41X2144	MS82x, MX721, MX722, MX82x Fuser Maintenance Kit, 230V, Type 06, A4	CRU	225,000			
	41X1076	MS82x, MX721, MX722, MX82x Fuser, 230V, Type 06, A4					
	41X1108	Transfer Roll					
	41X1119	Pick Roll (Qtyt 3)					
	41X1119	Separator Pad (Qty 3)					
41X2240	41X2145	MS82x, MX721, MX722, MX82x Fuser Maintenance Kit, 100V, Type 07, A4	CRU	225,000			
	41X1076	MS82x, MX721, MX722, MX82x Fuser, 100V, Type 07, A4					
	41X1108	Transfer Roll					
	41X1119	Pick Roll (Qtyt 3)					
	41X1119	Separator Pad (Qty 3)					
41X2241	41X2146	MS82x, MX721, MX722, MX82x Fuser Maintenance Kit, 115V, Type 08, A4	CRU	225,000			
	41X1076	MS82x, MX721, MX722, MX82x Fuser, 115V, Type 08, A4					
	41X1108	Transfer Roll					
	41X1119	Pick Roll (Qtyt 3)					
	41X1119	Separator Pad (Qty 3)					
41X2250	41X2155	MS82x, MX721, MX722, MX82x Return Program High Yield Fuser Maintenance Kit, 115V, Type 32, Letter	CRU	400,000			
	41X1076	MS82x, MX721, MX722, MX82x Return Program HY Fuser, 115V, Type 32, Letter					
	41X1108	Transfer Roll					
	41X1119	Pick Roll (Qtyt 3)					
	41X1119	Separator Pad (Qty 3)					
41X2251	41X2156	MS82x, MX721, MX722, MX82x Return Program High Yield Fuser Maintenance Kit, 230V, Type 33, Letter	CRU	400,000			
	41X1076	MS82x, MX721, MX722, MX82x Return Program HY Fuser, 230V, Type 33, A4					
	41X1108	Transfer Roll					
	41X1119	Pick Roll (Qtyt 3)					
	41X1119	Separator Pad (Qty 3)					
41X2252	41X2157	MS82x, MX721, MX722, MX82x Return Programm High Yield Fuser Maintenance Kit, 115V, Type 35, Letter	CRU	400,000			
	41X1076	MS82x, MX721, MX722, MX82x Return Program HY Fuser, 115V, Type 35, A4					
	41X1108	Transfer Roll					
	41X1119	Pick Roll (Qtyt 3)					
	41X1119	Separator Pad (Qty 3)					
41X2253	41X2158	MS82x, MX721, MX722, MX82x Return Program High Yield Fuser Maintenance Kit, 230V, Type 36, Letter	CRU	400,000			
	41X2158	MS82x, MX721, MX722, MX82x Return Program HY Fuser, 230V, Type 36, Letter					

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU	Yield
BOLD: Currently in-Marketing	TYPE	PN	PNs Included	Description (Note 1)	(Note 2)	(Note 3)
			41X1076 41X1108 41X1119	Transfer Roll Pick Roll (Qty 3) Separator Pad (Qty 3)		
W840, W850	4024	40X0958	40X0646 40X0594 40X0616	W840, W850 Fuser Maintenance Kit 100V Fuser assembly 100V (assembled), W840, W850 Feed unit roll kit Transfer roll assembly	FRU	300,000
		40X0956	40X0647 40X0594 40X0616	W840, W850 Fuser Maintenance Kit 110-120V Fuser assembly 110-120V (assembled), W840, W850 Feed unit roll kit Transfer roll assembly	FRU	300,000
		40X0957	40X0648 40X0594 40X0616	W840, W850 Fuser Maintenance Kit 220-240V Fuser assembly 220-240V (assembled), W840, W850 Feed unit roll kit Transfer roll assembly	FRU	300,000
		40X0603 40X0605 40X1387		Multipurpose feeder pick roll kit MPF transport roll kit Transport roll kit		
MS91x	4021	40X9669	40X9925 40X8970 40X9704	MS/MX 91x ITB 300K Maintenance kit Pick roller (2) Feed/Separator Roller (4) Imaging Transfer Kit <i>Imaging Transfer Kit includes the Transfer Belt, Transfer Roller, Exhaust Filter, Ozone Filter, and Printhead Cleaner, with their individual PNs shown below which are priced and may be purchased separately. The Image Transfer Belt is NOT priced separately.</i> Transfer Roller is included in 40X9704 Exhaust Filter is included in 40X9704 Ozone Filter is included in 40X9704 Printhead Cleaner is included in 40X9704	CRU CRU	300,000 300,000
		40X9936 40X9046 40X9673		Developer unit (600K) Fuser (Universal: 100V,110V,220V) MS/MX 91x MPF Kit (200K)	FRU FRU FRU	600,000 720,000 200,000
			40X9995 40X9615	MPF feed roller MPF separator roller		
MONO MULTIFUNCTION						
X203, X204	7011	40X2822		Transfer roll assembly	FRU	
X340 / X342	7003	40X2822		Transfer roll assembly	FRU	
X264, X363, X364	7013	40X5346 40X5344 40X5345 40X5807	40X7545 40X8419	Fuser assembly, 100V Fuser assembly, 110-120V Fuser assembly, 220-240V ADF maintenance kit ADF Separator roll Stress media separator pad	FRU FRU FRU CRU	120,000 120,000 120,000 60,000
X46x	7014	40X5402	40X5346 40X5451 40X5364	E46x, X46x Fuser Maintenance Kit 100V Fuser assembly, 100V Paper feed, ACM tires Transfer roll, bearings, gear, spring (CBM)	FRU	120,000
		40X5400	40X5344 40X5451 40X5364	E46x, X46x Fuser Maintenance Kit 110-120V Fuser assembly, 110-120V Paper feed, ACM tires Transfer roll, bearings, gear, spring (CBM)	FRU	120,000
		40X5401	40X5345 40X5451 40X5364	E46x, X46x Fuser Maintenance Kit 220-240V Fuser assembly, 220-240V Paper feed, ACM tires Transfer roll, bearings, gear, spring (CBM)	FRU	120,000
		40X5807	40X7545 40X8419	ADF maintenance kit ADF Separator roll Stress media separator pad	CRU	60,000
		40X5440 40X5451		Tray 2 paper feed tires Paper feed, ACM tires		
MX31x, MX41x	7015	40X8343 40X8023 40X8024 40X9077 41X0918 40X8393 40X8295 40X6247 41X0917 40X8736 40X9110		No Maintenance Kit (MK) announced and no Schedule 80 warning will appear on MX310 or MX410. However, the MX510 MK may be used and the published yield remains at 150,000 pages. Fuser, 100V Fuser, 110-120V Fuser, 220-240V Redrive assembly Pick Tire Transfer roll MPF pick roller and separator pad ADF separator pad, simplex ADF Separator Roller ADF pick roller Restraint pad	FRU FRU FRU FRU CRU FRU FRU CRU CRU FRU CRU	150,000 150,000 150,000 200,000 200,000 200,000 50,000 200,000 200,000 200,000 220,000 220,000 110,000
MX32x MB23x	7017	41X1180 41X1178 41X1179 40X8393 41X0918 41X1197 41X1239 41X1212 41X2223 40X6247 40X9110		No Maintenance Kit (MK) announced and no Schedule 80 warning will appear on MX32x. However, the MX52x MK may be used and the published yield remains at 200,000 pages. Fuser, 100V Fuser, 110V Fuser, 220V Transfer Roll Pick Tire MPF Pick Roller and Separator Pad Pick Roll Separator Roll Assembly RADF Pick Roll RADF Separator Roll RADF Restraint Pad	FRU FRU FRU FRU CRU FRU CRU FRU CRU CRU CRU	150,000 150,000 150,000 200,000 200,000 50,000 200,000 200,000 220,000 220,000 110,000
MB2236	3400	41X2463 41X2464 41X2455 41X2457 41X2480		No Maintenance Kit (MK) announced / no Schedule 80 warning will appear on B2236, MB2236 models. The yield of the consumable parts below are equivalent to the printer life, and therefore should not be considered in any TCO or CPP calculations. Fuser, 110V Fuser, 220V Pick Roller Transfer Roller ADF Pick Roller	FRU FRU FRU FRU	
MX42x MB24x	7017	41X1180		No Maintenance Kit (MK) announced and no Schedule 80 warning will appear on MX42x. However, the MX52x MK may be used and the published yield remains at 200,000 pages. Fuser, 100V	FRU	150,000

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU	Yield
BOLD: Currently in-Marketing	TYPE	PN	PNs Included	Description (Note 1)	(Note 2)	Pages (Note 3)
		41X1178 41X1179 40X8393 41X0918 41X1197 41X1239 41X1212 41X2223 41X2224 40X9110		Fuser, 110V Fuser, 220V Transfer Roll Pick Tire MPF Pick Roller and Separator Pad Pick Roll Separator Roll Assembly RADF Pick Roll RADF Separator Roll RADF Restraint Pad	FRU FRU FRU CRU FRU CRU FRU CRU CRU CRU	150,000 150,000 200,000 200,000 50,000 200,000 200,000 220,000 220,000 110,000
MX51x	7015	40X9146 40X9135 40X9136 41X0917 40X8736 40X9110 40X8443	40X8343 40X9077 41X0918 41X0958 40X8393 40X8444 40X8295 40X8023 40X9077 41X0918 41X0958 40X8393 40X8444 40X8295 40X8024 40X9077 41X0918 41X0958 40X8393 40X8444 40X8295	MX310, MX410, MX51x Fuser Maintenance Kit, 100V Fuser, 100V Redrive assembly Pick Tire Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad MX310, MX410, MX51x Fuser Maintenance Kit, 110-120V Fuser, 110-120V Redrive assembly Pick Tire Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad MX310, MX410, MX51x Fuser Maintenance Kit, 220-240V Fuser, 220-240V Redrive assembly Pick Tire Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad ADF Separator Roller ADF pick roller Restraint pad Pick roll assembly for optional trays	FRU FRU FRU CRU FRU CRU CRU	200,000 200,000 200,000 200,000 200,000 220,000 220,000 110,000
MX521 MB25x	7017	41X1230 41X1228 41X1229 41X1239 41X1212 41X2223 41X2224 40X9110	41X1180 41X1197 41X0918 40X8393 41X1178 41X1197 41X0918 40X8393 41X1179 41X1197 41X0918 40X8393	MX521 Fuser Maintenance Kit, 100V Fuser, 100V MPF Pick Roller and Separator Pad Pick Tire Transfer Roll MX521 Fuser Maintenance Kit, 110V Fuser, 110V MPF Pick Roller and Separator Pad Pick Tire Transfer Roll MX521 Fuser Maintenance Kit, 220V Fuser, 220V MPF Pick Roller and Separator Pad Pick Tire Transfer Roll Pick Roll Separator Roll Assembly RADF Pick Roll RADF Separator Roll RADF Restraint Pad	FRU FRU FRU CRU FRU CRU CRU CRU	200,000 200,000 200,000 200,000 220,000 220,000 110,000
MX522	7017	41X1230 41X1228 41X1229 41X1239 41X1212 41X1326 41X1325 41X1322	41X1180 41X1197 41X0918 40X8393 41X1178 41X1197 41X0918 40X8393 41X1179 41X1197 41X0918 40X8393	MX522 Fuser Maintenance Kit, 100V Fuser, 100V MPF Pick Roller and Separator Pad Pick Tire Transfer Roll MX522 Fuser Maintenance Kit, 110V Fuser, 110V MPF Pick Roller and Separator Pad Pick Tire Transfer Roll MX522 Fuser Maintenance Kit, 220V Fuser, 220V MPF Pick Roller and Separator Pad Pick Tire Transfer Roll Pick Roll Separator Roll Assembly DADF Pick Roll DADF Separator Roll DADF Restraint Pad	FRU FRU FRU CRU FRU CRU CRU CRU	200,000 200,000 200,000 200,000 220,000 220,000 220,000
MX61x	7015	40X9147 40X9137 40X9138 41X0917 40X8736 40X9110 40X8443	40X8343 40X9082 41X0958 40X8393 40X8444 40X8295 40X8023 40X9082 41X0958 40X8393 40X8444 40X8295 40X8024 40X9082 41X0958 40X8393 40X8444 40X8295	MX61x Fuser Maintenance Kit, 100V Fuser, 100V Redrive assembly Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad MX61x Fuser Maintenance Kit, 110-120V Fuser, 110-120V Redrive assembly Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad MX61x Fuser Maintenance Kit, 220-240V Fuser, 220-240V Redrive assembly Pick Roll Transfer roll Separator roll assembly MPF pick roller and separator pad ADF Separator Roller ADF pick roller Restraint pad Pick roll assembly for optional trays	FRU FRU FRU CRU FRU CRU CRU	200,000 200,000 200,000 200,000 220,000 220,000 110,000

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU	Yield
BOLD: Currently in-Marketing	TYPE	PN	PNs Included	Description (Note 1)	(Note 2)	(Note 3)
MX62x MB26x	7018	41X1227	41X1180	MX621, MX622 Fuser Maintenance Kit, 100V	FRU	200,000
			41X1197	Fuser, 100V		
			41X1198	MPF Pick Roller and Separator Pad		
			41X1212	Pick Tire		
		41X1225	41X1178	MX621, MX622 Fuser Maintenance Kit, 110V	FRU	200,000
			41X1197	Fuser, 110V		
			41X1198	MPF Pick Roller and Separator Pad		
			41X1212	Pick Tire		
		41X1226	41X1179	MX621, MX622 Fuser Maintenance Kit, 200V	FRU	200,000
			41X1197	Fuser, 200V		
41X1198	MPF Pick Roller and Separator Pad					
41X1212	Pick Tire					
41X1239	41X1197	MX621, MX622 Fuser Maintenance Kit, 200V	FRU	200,000		
	41X1198	Fuser, 200V				
	41X1212	MPF Pick Roller and Separator Pad				
	41X1322	Pick Tire				
X64x	7002	40X0100	40X0127	Dual Charge roll assembly	FRU	300,000
			40X0130	Transfer roll assembly		
			40X4308	Pick roll assembly (2 per package)		
			40X2592	T64x, X642e, X644e, X646e Fuser Maintenance Kit 110-120V		
		40X0101	40X0127	Fuser assembly w/115 V lamp	FRU	300,000
			40X0130	Dual Charge roll assembly		
			40X4308	Transfer roll assembly		
			40X2590	Pick roll assembly (2 per package)		
		40X8805	40X0127	T64x, X642e, X644e, X646e Fuser Maintenance Kit 220-240V	FRU	300,000
			40X0130	Fuser assembly w/220 V lamp		
40X4308	Dual Charge roll assembly					
40X4308	Transfer roll assembly					
40X0076	40X0453	ADF X64x Scanner Maintenance Kit	FRU	120,000		
	40X4656	ADF Pickup assembly				
		ADF Separator Roll				
		Pick roll assembly				
X65x	7462	40X4723	40X1870	T65x, X65xe Fuser Maintenance Kit 100V	CRU	300,000
			40X0127	Fuser assembly 100V, type 1		
			40X1886	Dual Charge roll assembly		
			40X4308	Transfer roll assembly with tool		
		40X4766	40X5853	Maintenance Kit 100V (Type 2)	CRU	150,000
			40X0127	Fuser assembly 100V, type 2		
			40X1886	Dual Charge roll assembly		
			40X4308	Transfer roll assembly with tool		
		40X4724	40X4418	T65x, X65xe Fuser Maintenance Kit 110-120V, type 1	CRU	300,000
			40X0127	Fuser assembly 110-120V, type 1		
			40X1886	Dual Charge roll assembly		
			40X4308	Transfer roll assembly with tool		
		40X4767	40X5854	Maintenance Kit 110-127V (Type 2)	CRU	150,000
			40X0127	Fuser assembly 110-120V, type 2		
			40X1886	Dual Charge roll assembly		
			40X4308	Transfer roll assembly with tool		
		40X4765	40X1871	T65x, X65xe Fuser Maintenance Kit 220-240V	CRU	300,000
			40X0127	Fuser assembly 220-240V, type 1		
40X1886	Dual Charge roll assembly					
40X4308	Transfer roll assembly with tool					
40X4768	40X5855	Maintenance Kit 220-240V (Type 2)	CRU	150,000		
	40X0127	Fuser assembly 220-240V, type 2				
	40X1886	Dual Charge roll assembly				
	40X4308	Transfer roll assembly with tool				
40X8778	40X4540	X65xe ADF Scanner Maintenance Kit	CRU	120,000		
	40X6406	ADF feed / pick roll assembly				
	40X3444	ADF Separator				
	40X4769	ADF platen cushion				
40X1883	40X4540	X65xe ADF Maintenance Kit	FRU			
	40X4605	ADF feed / pick roll assembly				
		X65xe ADF Separator Roll and Guide				
		MPF pick roll assembly with flanges and clip				
MX71x, MX81x	7463	40X7706	40X7593	MS81x, MX71x, MX81x Roller Maintenance Kit	CRU	300,000
			40X7582	Pick roller assembly		
			40X7713	Transfer roller		
			40X8420	Separator roller assembly		
		40X8421	40X7743	MS81x, MX71x, MX81x Return Program Fuser Maintenance kit, 110-120V, Type 00, Ltr	CRU	200,000
			40X7593	MS81x, MX71x, MX81x Return Program Fuser, 110-120V, Type 00, Ltr		
			40X7582	Pick roller assembly		
			40X7713	Transfer roller		
		40X8422	40X7744	MS81x, MX71x, MX81x Return Program Fuser Maintenance kit, 220-240V, Type 01, A4	CRU	200,000
			40X7593	MS81x, MX71x, MX81x Return Program Fuser, 220-240V, Type 01, A4		
			40X7582	Pick roller assembly		
			40X7713	Transfer roller		
		40X8423	40X7745	MS81x, MX71x, MX81x Return Program Fuser Maintenance kit, 100V, Type 02, A4	CRU	200,000
			40X7593	MS81x, MX71x, MX81x Return Program Fuser, 100V, Type 02, A4		
			40X7582	Pick roller assembly		
			40X7713	Transfer roller		
40X8424	40X7581	MS81x, MX71x, MX81x Return Program Fuser Maintenance kit, 110-120V, Type 03, A4	CRU	200,000		
	40X7593	MS81x, MX71x, MX81x Return Program Fuser, 110-120V, Type 03, A4				
	40X7582	Pick roller assembly				
	40X7713	Transfer roller				
40X8424	40X7581	MS81x, MX71x, MX81x Return Program Fuser Maintenance kit, 220-240V, Type 04, Ltr	CRU	200,000		
	40X7593	MS81x, MX71x, MX81x Return Program Fuser, 220-240V, Type 04, Ltr				
	40X7582	Pick roller assembly				
	40X7713	Transfer roller				

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU	Yield
BOLD: Currently in-Marketing	TYPE	PN	PNs Included	Description (Note 1)	(Note 2)	Pages (Note 3)
		40X8425	40X7593 40X7582 40X7713	Pick roller assembly Transfer roller Separator roller assembly MS81x, MX71x, MX81x Fuser Maintenance kit, 110-120V, Type 05, Ltr	CRU	200,000
		40X8426	40X8016 40X7593 40X7582 40X7713	MS81x, MX71x, MX81x Fuser Maintenance kit, 220-240V, Type 06, A4	CRU	200,000
		40X8427	40X8017 40X7593 40X7582 40X7713	MS81x, MX71x, MX81x Fuser Maintenance kit, 100V, Type 07, A4	CRU	200,000
		40X8428	40X8018 40X7593 40X7582 40X7713	MS81x, MX71x, MX81x Fuser Maintenance kit, 110-120V, Type 08, A4	CRU	200,000
		40X8429	40X8019 40X7593 40X7582 40X7713	MS81x, MX71x, MX81x Fuser Maintenance kit, 110-120V, Type 08, A4	CRU	200,000
		40X8431	40X8020 40X7593 40X7582 40X7713	MS81x, MX71x, MX81x Fuser Maintenance kit, 220-240V, Type 09, Ltr	CRU	200,000
		40X8431	40X7774 40X7775 40X7749	MX71x, MX81x ADF Maintenance Kit ADF pick roller ADF separator roller ADF feed belt	CRU	120,000
		40X7600		Multipurpose feeder pick roller	FRU	
MX725	7464	41X2352	41X1076 41X1108 41X1119	MS72x, MX72x, MS82x, MX82x Roller Maintenance Kit Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	450,000
		41X2351		MX72x, MX82x ADF Maintenance Kit	CRU	300,000
		41X2242	41X2147 41X1076 41X1108 41X1119	MS725, MX725 Return Program Fuser Maintenance Kit, 115V, Type 11 MS725, MX725 Return Program Fuser, 115V, Type 11 Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU CRU	225,000
		41X2243	41X2148 41X1076 41X1108 41X1119	MS725, MX725 Return Program Fuser Maintenance Kit, 220V, Type 13 MS725, MX725 Retrn Program Fuser, 220V, Type 13 Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000
		41X2244	41X2149 41X1076 41X1108 41X1119	MS725, MX725 Fuser Maintenance Kit, 115V, Type 17 MS725, MX725 Fuser, 115V, Type 17 Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000
		41X2245	41X2150 41X1076 41X1108 41X1119	MS725, MX725 Fuser Maintenance Kit, 220V, Type 19 MS725, MX725 Fuser, 220V, Type 19 Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000
MX721, MX722, MX82x MB2770	7464	41X2352	41X1076 41X1108 41X1119	MS72x, MX72x, MS82x, MX82x Roller Maintenance Kit Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	450,000
		41X2351		MX72x, MX82x ADF Maintenance Kit	CRU	300,000
		41X2233	41X1115 41X1076 41X1108 41X1119	MS82x, MX721, MX722, MX82x Return Program Fuser Maintenance Kit, 115V, Type 00, Letter MS82x, MX721, MX722, MX82x Return Program Fuser, 115V, Type 00, Letter Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU CRU	225,000
		41X2234	41X1116 41X1076 41X1108 41X1119	MS82x, MX721, MX722, MX82x Return Program Fuser Maintenance Kit, Type 01, 230V, A4 MS82x, MX721, MX722, MX82x Return Program Fuser, 230V, Type 01, A4 Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000
		41X2235	41X1117 41X1076 41X1108 41X1119	MS82x, MX721, MX722, MX82x Return Program Fuser Maintenance Kit, 100V, Type 02, A4 MS82x, MX721, MX722, MX82x Return Program Fuser, 100V, Type 02, A4 Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000
		41X2236	41X2141 41X1076 41X1108 41X1119	MS82x, MX721, MX722, MX82x Return Program Fuser Maintenance Kit, 115V, Type 03, A4 MS82x, MX721, MX722, MX82x Return Program Fuser, 115V, Type 03, A4 Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000
		41X2237	41X2142 41X1076 41X1108 41X1119	MS82x, MX721, MX722, MX82x Return Program Fuser Maintenance Kit, 230V, Type 04, Letter MS82x, MX721, MX722, MX82x Return Program, Fuser, 230V, Type 04, Letter Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000
		41X2238	41X2143 41X1076 41X1108 41X1119	MS82x, MX721, MX722, MX82x Fuser Maintenance Kit, 115V, Type 05, Letter MS82x, MX721, MX722, MX82x Fuser, 115V, Type 05, Letter Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000
		41X2239	41X2144 41X1076 41X1108 41X1119	MS82x, MX721, MX722, MX82x Fuser Maintenance Kit, 230V, Type 06, A4 MS82x, MX721, MX722, MX82x Fuser, 230V, Type 06, A4 Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000
		41X2240	41X2145 41X1076 41X1108 41X1119	MS82x, MX721, MX722, MX82x Fuser Maintenance Kit, 100V, Type 07, A4 MS82x, MX721, MX722, MX82x Fuser, 100V, Type 07, A4 Transfer Roll Pick Roll (Qtyt 3) Separator Pad (Qty 3)	CRU	225,000

Model	MACH	CONSUMABLE / WEAR PARTS			CRU/ FRU (Note 2)	Yield Pages (Note 3)
BOLD: Currently in-Marketing	TYPE	PN	PNs Included	Description (Note 1)		
		41X2241	41X2146 41X1076 41X1108 41X1119	MS82x, MX721, MX722, MX82x Fuser Maintenance Kit, 115V, Type 08, A4 MS82x, MX721, MX722, MX82x Fuser, 115V, Type 08, A4 Transfer Roll Pick Roll (Qty 3) Separator Pad (Qty 3)	CRU	225,000
		41X2250	41X2155 41X1076 41X1108 41X1119	MS82x, MX721, MX722, MX82x Return Program High Yield Fuser Maintenance Kit, 115V, Type 32, MS82x, MX721, MX722, MX82x Return Program HY Fuser, 115V, Type 32, Letter Transfer Roll Pick Roll (Qty 3) Separator Pad (Qty 3)	CRU	400,000
		41X2251	41X2156 41X1076 41X1108 41X1119	MS82x, MX721, MX722, MX82x Return Program High Yield Fuser Maintenance Kit, 230V, Type 33, MS82x, MX721, MX722, MX82x Return Program HY Fuser, 230V, Type 33, A4 Transfer Roll Pick Roll (Qty 3) Separator Pad (Qty 3)	CRU	400,000
		41X2252	41X2157 41X1076 41X1108 41X1119	MS82x, MX721, MX722, MX82x Return Programm High Yield Fuser Maintenance Kit, 115V, Type 3 MS82x, MX721, MX722, MX82x Return Program HY Fuser, 115V, Type 35, A4 Transfer Roll Pick Roll (Qty 3) Separator Pad (Qty 3)	CRU	400,000
		41X2253	41X2158 41X1076 41X1108 41X1119	MS82x, MX721, MX722, MX82x Return Program High Yield Fuser Maintenance Kit, 230V, Type 36, MS82x, MX721, MX722, MX82x Return Program HY Fuser, 230V, Type 36, Letter Transfer Roll Pick Roll (Qty 3) Separator Pad (Qty 3)	CRU	400,000
X85x	7500	40X2377	40X2378 40X0594 40X0616	X85xe, X86xe Fuser Maintenance Kit 100V Fuser assembly 100V Feed unit roll kit Transfer roll assembly	FRU	300,000
		40X0394	40X2503 40X0594 40X0616	X85xe, X86xe Fuser Maintenance Kit 110-120V Fuser assembly 110-120V Feed unit roll kit Transfer roll assembly	FRU	300,000
		40X0398	40X2504 40X0594 40X0616	X85xe, X86xe Fuser Maintenance Kit 220-240V Fuser assembly 220-240V Feed unit roll kit Transfer roll assembly	FRU	300,000
		40X2377	40X2378 40X0594 40X0616	X85xe, X86xe Fuser Maintenance Kit 100V Fuser assembly 100V Feed unit roll kit Transfer roll assembly	FRU	300,000
		40X2734	40X2280 40X2273	X85xe, X86x ADF Maintenance Kit ADF feed/pick roll assembly (assembled) Separation roll guide assembly (assembled)	FRU	150,000
		40X0603		Multipurpose feeder pick roll kit	FRU	
		40X0605		MPF transport roll kit	FRU	
		40X0770		Feed unit roll kit	CRU	
		40X0792		Duplex media transport pinch roll kit	FRU	
		40X0793		Duplex media transport roll kit	FRU	
X86x	7500	40X2377	40X2378 40X0594 40X0616	X85xe, X86xe Fuser Maintenance Kit 100V Fuser assembly 100V Feed unit roll kit Transfer roll assembly	FRU	300,000
		40X0394	40X2503 40X0594 40X0616	X85xe, X86xe Fuser Maintenance Kit 110-120V Fuser assembly 110-120V Feed unit roll kit Transfer roll assembly	FRU	300,000
		40X0398	40X2504 40X0594 40X0616	X85xe, X86xe Fuser Maintenance Kit 220-240V Fuser assembly 220-240V Feed unit roll kit Transfer roll assembly	FRU	300,000
		40X2734	40X2280 40X2273	X85xe, X86x ADF Maintenance Kit ADF feed/pick roll assembly (assembled) Separation roll guide assembly (assembled)	FRU	150,000
		40X0603		Multipurpose feeder pick roll kit	FRU	
		40X0605		MPF transport roll kit	FRU	
		40X0695		Media transport roll assembly kit	FRU	
		40X0770		Feed unit roll kit	CRU	
		40X1387		Transport roll kit	FRU	
MX91x	7421	40X9669	40X9925 40X8970 40X9704	MS/MX 91x ITB 300K Maintenance kit Pick roller (2) Feed/Separator Roller (4) Imaging Transfer Kit <i>Imaging Transfer Kit includes the Transfer Belt, Transfer Roller, Exhaust Filter, Ozone Filter, and Printhead Cleaner, with their individual PNs shown below which are priced and may be purchased separately. The Image Transfer Belt is NOT priced separately.</i> Transfer Roller is included in 40X9704 Exhaust Filter is included in 40X9704 Ozone Filter is included in 40X9704 Printhead Cleaner is included in 40X9704	CRU	300,000
		40X9936		Developer unit (600K)	FRU	600,000
		40X9046		Fuser (Universal: 100V,110V,220V)	FRU	720,000
		40X9673	40X9995 40X9615	MS/MX 91x MPF Kit (200K) MPF feed roller MPF separator roller	FRU	200,000
		40X9672	40X8879 40X9681 40X9682	MX 91x ADF Kit (200K) ADF pick roller (2) ADF feed roller ADF separator roller	FRU	200,000
SCANNER						
4600		40X2540 40X4755		4600 MFP Option Pick Roller 4600 MFP Option Pick Roll Pad	FRU FRU	120,000 40,000
6500 6500		40X6446 40X8376		ADF pick roller ADF separator pad	FRU CRU	
FI-6140/6240/6130		PER6212		ScanAid Cleaning and Consumable Kit Brake Roller (1) Pick Roller (1)	CRU	200,000 200,000 200,000
FI-6670 6770		PER6213		ScanAid Cleaning and Consumable Kit Pick Roller (1) Brake Roller (1)	CRU	250,000 250,000 250,000
FI-6800		PER6217		ScanAid Cleaning and Consumable Kit	CRU	600,000

				Pick Roller (1) Brake Roller (1) Separator Roller (1)		600,000 600,000 600,000
FI-4530C/5530C		PER6218		ScanAid Cleaning and Consumable Kit Pad Assemblies (5) Pick Roller Units (2)	CRU	100,000 100,000 250,000
FI-5900C/5950		PER6220		ScanAid Cleaning and Consumable Kit Pad Assembly (1) Pick Roller (1) Brake Roller (1) Separation Roller (1)	CRU	600,000 600,000 600,000 600,000

LEGEND:

- Note 1 Voltage guideline: (Check voltage [V] requirements for the country of installation)
100V-Japan Only;
110-127V US & Canada;
220-240V Most of Europe, Asia Pacific and Latin America
- Note 2 CRU: Customer Replaceable Unit
FRU: Field Replaceable Unit; Service Technician Required
- Note 3 Page Yield is based on extensive Lexmark testing
Actual Yield may vary since many factors may affect parts yield, including media type, environment, usage, etc.